


User Name

•••••

LOG IN Remember Me?

EnclaveForum.net: Buick Enclave Online Community > Technical Discussions > Engine & Drivetrain > Changing fuel injectors myself



Report this image

2) In order to remove the intake manifold, first disconnect all of the various hoses and wire harnesses from the manifold. Disconnect any connectors

completely remove them from the vehicle. Remove the air intake tube. This is how it should look just before you remove the intake manifold.

Page 2 of 3 < 2 > -




Report this image

3) Next remove the 6 13mm bolts that hold down the air manifold. I keep them organized so they go back in the same hole they came out. Remove manifold and set it aside. Be careful not to damage gasket (I have reused this gasket multiple times).



Report this image

4) Now remove the foam molded fuel shields. The one over the fuel pump



Report this image



Report this image



Report this image

5) Now you can see the High pressure fuel rails, jumper lines, fuel pump, and pressure sensor. All very tightly packed into the Vee of the engine. Not



Report this image

6) Remove the 2 jumper lines with yellow tags (pump to right rail, right to left rail). These are not to be reused.



Report this image

7) Disconnect and remove the high pressure fuel sensor with a deep-well 27mm socket. This part must also not be reused. Remove the 4 13mm bolts on each fuel rail. Again I kept them organized so they all went back together in the same hole. There is a small black plastic bushing on each bolt...be careful not to loose them as you remove the bolts (most of mine stayed in the fuel rail).

9) Now remove the fuel rails. This is where it got a little tricky because everything is so tight. The right fuel rail (w/o sensor) is easier to remove. But it requires some constant pressure and wiggling to get the injectors to dislodge from the cups on the fuel rails. In fact the injectors may want to come out with the fuel rail but you don't want that to happen since they are also attached to the wire harness. The left fuel rail must be removed rearend first, then twisted as you raise the rear end to dislodge the front end of the rail from between the intake port and another part of the engine. Just take your time and be patient, it will all come out.

Page 2 of 3 < 2 >



Report this image

10) Next the injectors need to be carefully removed. Each bank is attached together on a plastic wire harness so your best bet is to loosen each injector from the hole and then pull out an entire bank at once. Some of the injectors dislodged while I was pulling the fuel rails. The ones that did not I just used a pair of pliers to pull them free since I was replacing them anyways. Disconnect the wire harness and move the entire assembly to the work bench.



Report this image

Page 2 of 3 < 2 >




Report this image

11) Here is the failed #5 injector. Only visible difference was it was wet on the tip, likely from dumping fuel.



Report this image

12) The engine with injectors removed. I once again vacuumed very well to get any dirt and debris our of the injector holes.



Justin-PA Jr. Member	Re: Changing fuel injectors myself
Join Date: Nov 2014 Posts: 34	PART 2: 13) Note: The injectors I bought came pre-loaded with all new seals and o-
	rings and a new hold-down clamp. Needless to say these all should be new when installing new injectors. It is possible to buy injectors without the seals which is a bad idea for a DIY'er since there are a couple special tools required to seat the various seals on the injector. Remove the old injectors from the wire harness and install the new ones including the new hold-down clamps. Note the injectors must be oriented a certain way as dictated by the plastic wire harness.



Report this image



Report this image


14) Carefully seat the new injectors and wire harness assemblies back into the holes in the engine. Push each injector in as far as possible with your thumb, making sure it stays properly aligned. Connect the injectors harness connectors as required.

15) Now reinstall the fuel rails. Before doing so coat the injector o-rings and the fuel rail cups with silicone-free engine oil. The left rail is tricky, put the front edge of the rail into the engine, and twist as you lower the rail down into the Vee. Make sure all 3 cups are centered over the injectors. You should be able to push down on the rail and get the injectors seated into the fuel rail cups most of the way by hand. Install the right rail which is a little easier.

Put the front end in first:

1 This image has been resized. Click this bar to view the full image.

Page 2 of 3 < 2 > -



Report this image

Then twist and lower the rear end into the Vee.



Report this image

16) Now re-install the fuel rail bolts and tighten them in 2 steps starting at bolt 1, then 4, then 2, then 3. (Bolts numbered starting at #1 at the front of the engine). Check the Envlave maintenance docs for torque values.

17) Install a new pressure sensor with 27mm deep socket. Be sure to oil the threads in the fuel rail and on the sensor, hand-tighten, remove and oil

Page 2 of 3 < 2 > -

1 \bigodot Install new high pressure fuel lines, making sure to oil all the threads, and torque as required.



Report this image

19) Check for fuel leaks by turning ignition to on (engine not running!) for 2 seconds, off for 10 seconds, and then back on. Look for any leaks at all connections. There must be no leaks!

20) Now reinstall the foam shields, air manifold (torque bolts as required), and all hoses, tubes, and electrical connectors previously removed.

21) Clear all previously stored codes, start the engine and look for leaks under the hood, or other signs of trouble. Note that since my injector had failed there was A LOT of un-burned fuel in the exhaust that had to be burnt out. My garage became a white cloud of smelly smoke very quickly (all doors were open!!). I took it for a 5 mile drive and it was pretty well cleared up by then.

CODES BEFORE: 👰

Click this bar to view the full image.

Diagnostics

STORED CODES

P0300

Engine Misfire Detected

P0305

Cylinder 5 Misfire Detected

P0089

Fuel Pressure Regulator 1 Performance

P02AD



Throttle Position (TP) Sensor Circuit Low Voltage

Read Codes

Clear Codes

